

## CONTENTS 20X20:

8 two piece side poles (16 total pieces) \*\*COLOR CODED BLACK

1 four piece center pole (4 total pieces) \*\*COLOR CODED BLUE


12 -18" steel stakes

12 tensioning straps (attached to canopy)

1 pole bag

## SET UP:

1. Spread the canopy flat and pull the corners square.
2. Pull straps out perpendicular to the edge of the canopy. See [diagram](#).



3. Place stakes in the ground at each strap [location](#), approximately 4' from tent's edge. Hammer the stakes into the ground at a 30-45 [degree angle](#) away from the tent. Loop the strap over each stake.
4. Put side poles together, one bottom, capped pole and one pointed, top pole.

5. Place the four corner poles into position with the bottom slightly inward, toward the center. Tighten straps until snug.
6. Put up the other side poles and tighten straps.
7. Erect one 3 piece center pole and position (one bottom capped pole, one middle pole and one pointed, top pole). **IMPORTANT: Tie the jumper rope to the center pole. This keeps the canopy from lifting off of the center pole.**
9. Go back around canopy and tighten all straps until the canopy is taut.
10. CAUTION: DO NOT decorate the tent with crepe paper or any material that will stain the canopy top.
11. Grilling and cooking should NOT be done under the canopy.

**TAKE DOWN: DO NOT REMOVE TENSIONING STRAPS FROM CANOPY**

1. Take down canopy when dry and return in appropriate bags.
2. Loosen Straps and remove center pole followed by side poles.
3. Pull up stakes and fold up dry canopy. (NOTE: leaves folded up with the canopy will cause permanent stains)